



## FLEXAMAT CHANNEL - LAYOUT PERPENDICULAR TO FLOW

### CONSTRUCTION NOTES:

1. AN AUTHORIZED MANUFACTURERS REPRESENTATIVE SHALL BE ONSITE FOR THE START OF THE INSTALLATION.
2. GRADE CHANNEL SO THAT WATER WILL FLOW DOWN CENTER OF THE CHANNEL AND BE CONTAINED TO THE CHANNEL. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND.
3. PRIOR TO FLEXAMAT PLUS INSTALLATION, SEED AND FERTILIZE SUBGRADE WITH SITE SPECIFIC SEED MIX.
4. INSTALL FLEXAMAT PLUS ROLLS THAT ARE 15.5' WIDE WITH A 12" GEOGRID EXTENSION AND 6" PLUS UNDERLAYMENT EXTENSION.
  - 4.1. INSTALL MATS SO THAT THE MATTING EXTENDS 3' PAST THE CREST OF EITHER SIDE SLOPE. MATS SHALL BE CONTINUOUS SECTIONS ACROSS THE CHANNEL, INCLUDING AREAS PAST CREST OF SIDE SLOPES.
  - 4.2. OUTSIDE EDGES SHALL BE EMBEDDED IN AN 18" 45 DEGREE ANCHOR TRENCH. INSTALL UPSTREAM MATS OVER THE GEOGRID EXTENSION OF DOWNSTREAM MATS.
5. INSTALL 18" U-ANCHORS (FOR COHESIVE SOILS) IN 2' INCREMENTS ACROSS MAT ABUTMENT SEAMS. INSTALL ANCHORS DIRECTLY BEHIND BLOCKS. U-ANCHORS SHALL ENCOMPASS 2 CORDS OF GEOGRID FROM BOTH MATS. INSTALL 20" STAINLESS STEEL ZIP TIES (FOR NON-COHESIVE SOILS) IN 1' INCREMENTS ACROSS MAT ABUTMENT SEAM. ZIP TIE SHALL ENCOMPASS A MINIMUM OF THREE CORDS OF GRID OF EITHER MAT AT ABUTMENT SEAMS.
6. AT THE LEADING EDGE OF ARMORED CHANNEL, EMBED MAT 18" IN A VERTICAL ANCHOR TRENCH. FILL AND COMPACT ANCHOR TRENCH WITH COHESIVE SOIL. AT ENDING EDGE OF PROTECTION, INSTALL 18" TERMINATION TRENCH AS DETERMINED BY THE EOR.

**MOTZ  
ENTERPRISES, INC.**

**Flexamat**

**Telephone: (513)772-6689**

**Email: [Info@Flexamat.com](mailto:Info@Flexamat.com)**

**Webstie: [Flexamat.com](http://Flexamat.com)**

